DUNCAN SELF DRIVE

FORD TRANSIT 350 XLWB FLATBED

L4 | EXTRA LONG WHEELBASE | OPEN-BACK DROPSIDE

Representative L4 RWD single-cab example • Body sizes and payloads vary

4.15 m	9.12 m²	~27 MPG
LOAD-BED LENGTH	LOAD-BED FLOOR AREA	UK MPG • DIESEL MANUAL

EXTERIOR DIMENSIONS

Overall length	**6,710 mm**
Width, including mirrors	**2,474 mm**
Overall height[1]	**2,215 mm**
Wheelbase	**3,954 mm**
Seating capacity	**3 seats**
Fuel tank capacity	**75 litres**

LOAD-BED DIMENSIONS

Internal bed length	**4,145 mm**
Internal bed width	**2,200 mm**
Dropside height	**400 mm**
Load-bed floor area[2]	**9.12 m²**
Roof / load enclosure	**Open top**
Enclosed cubic capacity[2]	**Not applicable**

OPEN-BACK BODY

Body style	**Flatbed with folding dropsides**
Body type	**Open load bed**

WEIGHTS • 3.5-TONNE EXAMPLE

Gross vehicle weight	**3,500 kg**
Calculated unladen weight[3]	**2,250 kg**
Payload allowance[3]	**1,250 kg**

APPROX. FUEL ECONOMY

~27 MPG

UK gallons • combined guide figure

2.0 EcoBlue 165 PS • manual RWD.
Load, traffic and driving affect results.

EXAMPLE FIGURES - CONFIRM YOUR VEHICLE BEFORE DISPLAY / HIRE

[1] Height is an unladen example; gantries, racks and loads can increase overall height.
[2] Open load bed: no fixed enclosed cubic capacity. Floor area = bed length × width.
[3] Payload supplied by operator; unladen weight calculated as 3,500 - 1,250 kg.
Confirm actual laden weight and observe the vehicle gross and axle limits.
Body builder, year, equipment and load restraints affect usable space and available payload.

Source: Dawsongroup Transit 350 L4 RWD 165 PS Leader Dropside specification.